



## Shingle Roof

### Installation:

1. The rounded nose of the TEK-MESH should be installed with the edge of the gutter.
2. The bottom flap needs to sit firmly in the space between the lip of the gutter and the gutter brackets or nails (if used). Should another gutter protector be used which fastens the gutter to the fascia, the Tek-Mesh can be slid directly above the screen.
3. The rear flat section of TEK-MESH is to be screwed down either:
  - under the first row of shingles (making a bend for the angle of the roof)
    - or
  - under a corrugated metal roof
    - or
  - against the fascia, bending it at 90 degrees and screwing it down in cases such as a tar and gravel roof or low pitch roof of 1/12 or 2/12 or 3/12.



4. The flat section should be screwed down with 1 ½ deck screws and silicone sealant be applied after.

### Comments:

When installing each 5 ft. piece, there is a ½" overlap where ½ inch coated screws are used to screw the sheets together. After TEK-MESH is installed on the gutter, an end cap is to be installed (either a left cap or a right cap) to keep birds from entering by the sides. These end caps are to be trimmed with metal cutters and screwed down (with ½ inch screws) to the edge of the TEK-MESH micro-screen.